



## Installing the Ceiling Mounting Kit

Please refer to the following recommendations for installing the Ceiling Mounting Kit.

1. The Ceiling Mounting Kit is ready to be installed into a wood ceiling material, such as conventional overhead floor joist (wood screws are provided).
2. Use the diagram below to lay out the orientation of your particular installation, and mark out the centerline pattern for your mounting kit. You may need to obtain and mount additional wood (such as two 2x6's) in order to have the pattern land on a solid wood mounting point (see diagram).
3. Mount the foot plates (4) centered on the corners of the pattern, using the 8 wood screws included. You may need to drill pilot holes for the screws.
4. Assemble the rod, nut, vibration isolator and eye sockets as shown.
5. Hang the unit from the four ceiling supports using the provided S hooks, and the D-rings on the outside of the unit.
6. You can now complete your wiring and duct installation for the ERV. Refer to the Owner's Manual / Installation Guide for more information.

